



## Installation instructions for the Fixpod

### Step 1:

M20 – Ø25mm drilling  
 M25 – Ø30mm drilling  
 M40 – Ø45mm drilling  
 in wood material  
 (at least 15mm thick!)



### Step 2:

Push the Fixpod with the funnel upwards, flush with the surface, into the hole (self-locking)



### Step 3:

Insert the installation pipe from the back to the stop edge. So that the pipe is fixed by the integrated grid

**Please take care:** In order to ensure a smooth realisation, all processes must already take place in the production flow of the element production!

#### Step 4:

Please repeat step 1-3 for the elements to be connected



#### Step 5:

When assembling, you can use the two prepared elements flush together



#### Step 6:

As soon as the elements are finally connected, the installations can be carried out. The pull-in direction is possible on both sides.

As an additional supplement, the Fixpod can be used not only for element transitions, but also for any wall + ceiling outlets. Here we have the same procedure as in step 1-3

