



Installation instructions for the Fixpod

Step 1:

Ø30mm drill hole in wood-based material (at least 15mm thick!)



Step 2:

Push the Fixpod with the funnel upwards, flush with the surface, into the hole (self-locking)



Step 3:

Insert the installation pipe from the back to the stop edge. So that the pipe is fixed by the integrated grid

Please take care: In order to ensure a smooth realisation, all processes must already take place in the production flow of the element production!

Step 4:

Please repeat step 1-3 for the elements to be connected



Step 5:

When assembling, you can use the two prepared elements flush together



Step 6:

As soon as the elements are finally connected, the installations can be carried out. The pull-in direction is possible on both sides.

As an additional supplement, the Fixpod can be used not only for element transitions, but also for any wall + ceiling outlets. Here we have the same procedure as in step 1-3

